



## INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS

1455 Kleppe Lane ♦ Sparks, NV 89431-6467 ♦ (775) 359-4712 ♦ Fax (775) 359-7424  
E-mail: [haws@hawsco.com](mailto:haws@hawsco.com) ♦ website: [www.hawsco.com](http://www.hawsco.com)

No. 0002080222 (17)

# Model 9082 Antimicrobial Preservative Concentrate Eyewash Additive

### TO ORDER MORE EYE WASH STATION PRESERVATIVE CONCENTRATE:

Contact your nearest Haws Representative or call Haws Customer Service at  
1-888-640-4297, Sparks, Nevada.

### WARNING:

1. MUST BE DILUTED WITH **POTABLE** WATER. DO NOT PUT DIRECTLY INTO EYES. Do not use if tamper evident seal is broken or missing.
2. Contact with the eyes and mucosa can cause irritation, redness and pain.

### Mixing Instructions

Follow instructions on the side of each bottle. Units with capacities of 5 gal - 20 gal (18.9 L – 75.7 L) should be mixed with the full 8 oz (236 ml) contained in each bottle. It is recommended that the tentative potable water be replaced every 120 days. (After any 15-minute testing per ANSI Z358.1-2014, refill tank with clean potable water and add contents of new 9082 Antimicrobial Preservative Concentrate Eyewash Additive, following instructions on the side of each bottle).

### Storage Instructions

Product should be stored between 68° F - 77° F  
(20° C - 25° C)

Use before expiration date.

36 Month shelf life after date of manufacture.

© 2019 Haws® Corporation – All Rights Reserved  
HAWS® and other trademarks used in these materials are the exclusive property of Haws Corporation.